

# Mitsubishi Asx 2015> -- SWC Interface



In order to prevent ESD damage, the W/R Jack must be connected before plugging the connectors on car side

